



JP1 = Bootloader

USB only for Bootloader